

WorkBee 1000x1500mm Belt & Screw Drive Manual Guide

As you have purchased a 1000x1500mm Belt & Screw Driven Machine, you will need to use both the WorkBee-Belt-Assembly and WorkBee-Screw-Assembly-Manuals. Below is breakdown of which manuals to use where.

Section 2.1 – Belt-Assembly-Manual

Section 2.2 – Belt-Assembly-Manual (Also complete Section 2.2.3 from Screw-Assembly-Manual)

Section 2.3 – Screw-Assembly-Manual

Section 2.4 – Screw-Assembly-Manual

Section 2.5 – Belt-Assembly-Manual

Section 2.6 – Belt-Assembly-Manual

Section 2.7 – Belt-Assembly-Manual

Section 2.8 – Belt-Assembly-Manual (For Y-Axis Only, Ignore X-Axis)

Use the Full-Kit-Assembly-Manual as usual once the mechanical portion is complete.